


## THEATER VIEWING INSTRUCTIONS

1. Turn on projector by pressing blue power button  once.
2. On the ROKU remote, press the home button.
3. Navigate to the streaming option of your choice.
4. The volume is controlled by the Yamaha surround sound system located behind the door (make sure powered on)



## DVD Instructions

1. Power on Sony DVD player.
2. Press BD DVD button
3. Insert DVD and press play. When you get to menu screen, press stop and then play to start movie.



\*To return to TV viewing use INPUT button to navigate to HDMI2

\*\*To turn off projector, press power button twice.